




Light-GPS Instructions




Safety Warning


1. Please read the safety instructions carefully and keep for future reference.
2. Pay attention to all warning and indication signs on the product.
3. To protect your eyes, do not look directly at the headlight.
4. Please keep this product out of children's reach.
5. Keep the product away from all heat sources.
6. Do not pour or insert liquids or other objects into the product.
7. Do not attempt to repair the product yourself.
8. Please wear a helmet and a reflective jacket when riding.
9. To ensure safety, please inform your family and friends of your whereabouts before setting off.



As shown to the left, fix the base to the handlebars then insert screws from top. Do not over tighten the screws. Too much force can cause the bracket to break.




Align the light with slot and push backwards. There is a lever at the rear and when fully pushed in, it will lock in place. If it is not fully pushed in, the light may come off during riding.




When removing the main unit, first press down the lever at the rear, and then push the main unit forward.

GPS Operation

Press and hold the power button for 3 seconds to activate/deactivate LED screen.



NOTE: Satellites can only be searched for outdoors. When using it for the first time, it will take a few minutes to search for satellites


When the satellite icon  stops flashing, the satellite search is completed. There is a memory function, so for subsequent use it only takes a relatively short time to complete the satellite search.

If the satellite cannot be searched within 20 minutes, or there is no speed display, the unit will automatically turn off to save energy, unless headlight is on.

- To turn back light on/off: Press and hold SET button for 3 seconds.
- TRIP DIST and TRIP TIME record the data of each ride. This data is reset each time the GPS is turned off.
- TOTAL DIST and TOTAL TIME will always be saved and will not be cleared.
- Press SET key to switch between TOTAL DIST, TOTAL TIME, TRIP TIME, CLOCK and CALORIES
- Press the MODE key to switch between NOW, MAX and AVG SPEEDS.

Setting Modes:

Press and hold the SET key and the MODE key together for 3 seconds. Mileage (kilometres or miles), and your weight (unit: KG). Press the SET key to select the desired value then press the MODE key to jump to the next setting step, and finally the POWER key to save the settings and exit.



NOTE: to restore to factory settings: Press and hold the SET key and the MODE key for 10 seconds, and all the numbers on the display screen will light up, restoring the factory settings. (Or press the SET, POWER and MODE keys simultaneously for 1 second.)

Headlight Operation

To activate light, long press the power button LED display will turn on. Then single press power button to turn light on. Once light is on single press power button to activate each mode or double press to activate high beam. To turn off light (including GPS) long press the power .

- Mode 1: Smart mode, high beam when riding, low beam when stationary (after 1 minute). When you continue riding it will automatically switch back to high beam.
- Mode 2: Low beam 200lm.
- Mode 3: Slow flash 450lm.
- Mode 4: Double press for high beam 450lm, or single press to turn light off